

# TECNA<sup>®</sup>



## MEDIUM FREQUENCY RESISTANCE WELDER

### ITEMS 6121 - 6126

## INSTALLATION AND USE INSTRUCTION MANUAL

TECNA S.p.A. Via Grieco 25/27 - 40024 Castel S. Pietro Terme - Bologna ITALY Pho.+39.051.6954400 – Tel.051.6954410 – Fax.+39.051.6954490	
<b>DOCUMENT NUMBER:</b>	<b>DISTRIBUTOR:</b>
<b>EDITION:</b>	<b>DECEMBER 2004</b>

## INDEX

	<b>CONTENTS</b>	<b>PAGE</b>
1	INTRODUCTION	3
1.1	PRELIMINARY REMARKS	3
1.2	SYMBOLS ON BOTH WELDER AND MANUAL	3
1.3	STANDARD ACCESSORIES	3
2	TECHNICAL FEATURES	4
2.1	IDENTIFICATION DATA	4
2.2	ELECTRICAL DATA	4
2.3	MECHANICAL DATA	5
2.4	COMPRESSED AIR CONNECTIONS DATA	5
2.5	COOLING CIRCUIT CONNECTIONS DATA	6
2.6	ADDITIONAL FEATURES	6
2.7	MAIN WELDER FEATURES	7
2.8	WELDING CONTROL UNIT TE600 DESCRIPTION	8
3	INSTALLATION	9
3.1	PLACE OF INSTALLATION	9
3.2	UNPACKING AND TRANSPORT	9
3.3	PNEUMATIC INSTALLATION	9
3.4	COOLING WATER CONNECTION	10
3.5	ELECTRICAL INSTALLATION	10
4	WORKING PROCESS	11
4.1	MECHANICAL SET UP	13
4.2	ELECTRODE FORCE ADJUSTMENT	15
4.2.1	STANDARD PNEUMATIC CIRCUIT ADJUSTMENT	15
4.2.2	LOW FORCE SQUEEZE PNEUMATIC CIRCUITS ADJUSTMENT	16
4.3	WORKING PROGRAM ADJUSTMENT	17
4.4	CALCULATION OF THE MAXIMUM WELDING RATING	18
5	SAFETY RULES	19
6	ACCESSORIES AND SPARE PARTS REQUEST	20
7	MAINTENANCE	21
7.1	ORDINARY MAINTENANCE	21
7.2	EMERGENCY CONDITION WARNINGS	22
7.3	EXTRAORDINARY MAINTENANCE	23
7.3.1	LOWERING OF THE WELDING UNIT PERFORMANCES	23
7.3.2	TROUBLESHOOTING	23
7.3.3	REMEDIES FOR WELDS IMPERFECTIONS	26
8	ENCLOSURES	27
8.1	WELDING TABLES	27
8.2	PRODUCTION FORM FACSIMILE	31

## 1 INTRODUCTION

### 1.1 PRELIMINARY REMARKS

#### CAREFULLY READ THIS MANUAL BEFORE INSTALLING AND OPERATING WELDER.




This manual is addressed to the factory responsible in charge who must release it to the personnel in charge of both welder installation, use and maintenance. He/she must check that the information given in this manual and in the enclosed documents have been read and understood. The manual must be stored in a well-known place, easy to reach, and must be looked up each time even little doubts should arise.

This welder has been designed for resistance welding of both ferrous and not ferrous (aluminium, brass) materials. The welder must not be used for other application, i.e. pieces heating, mechanical working carried out by using the electrodes force. The welder has been designed to be used by an operator by means of the foreseen control devices. All modifications, even slight ones, are forbidden because they should invalidate the welder CE certification.

The welders described in this manual have been designed to be used only for professional purposes in industrial environments. They must not be installed on public low voltage network which supplies domestic premises. This can cause electromagnetic interferences.

TECNA S.p.A is not responsible for any damage to both people, animals, things and to the welder itself caused by either a wrong use or the lack or the superficial observance of the safety warnings stated on this manual, nor it is responsible for damages coming from even slight tampering or from the use of not-suitable spare parts, or of spare parts other than the original ones.

### 1.2 SYMBOLS ON BOTH WELDER AND MANUAL

	WARNING! Danger of squashing.
	Double stroke control device.
	WARNING! Important safety information enclosed in this paragraph.

### 1.3 STANDARD ACCESSORIES

The welder is supplied equipped with the following accessories:

- N° 1 Allen wrench set 4-5-6-8-10 mm.
- N° 1 Hexagonal key 19 mm.
- N° 1 Electrodes extractor.
- N° 1 High conductivity grease pot.
- N° 1 Straight electrodes, a pair, item 8701.
- N° 1 Offset electrodes, a pair, item 8703.
- N° 1 Control unit TE600 instruction manual.
- N° 1 Welder instruction and maintenance manual.
- N° 1 Technical documentation booklet.
- N° 1 Wrap-it-ties and hose clamps set.
- N° 1 Spare silencers set.

Check that the welder is equipped with all the standard accessories; immediately inform the manufacturer in case some components should lack.



**2.3 MECHANICAL DATA**

Item		6121-6124	6122-6125	6123-6126
Electrodes throat depth	L = mm	385	535	800
Projection plates throat depth	D = mm	260	410	-

Electrode-holder	<input type="checkbox"/> Standard Ø 32 mm <input type="checkbox"/> Special Ø .....
Electrodes cone	<input type="checkbox"/> Standard Ø 19,05 mm 3/4" 2°30' BS 807 <input type="checkbox"/> Special Ø .....
Projection plates	<input type="checkbox"/> Standard centreline 63 mm for M12 nuts <input type="checkbox"/> Special .....

Pneumatic circuit		<input type="checkbox"/> Standard Ø 125	<input type="checkbox"/> Optional Ø 125 × 2
Electrode force per bar (100 kPa)	daN	123	207
Electrode force at 6 bar (600 kPa)	daN	736	1242
Maximum stroke	mm	100	100
Adjustable Double stroke	mm	0÷80	0÷80

**2.4 COMPRESSED AIR CONNECTIONS DATA**

Minimum pressure	bar	6,5
	kPa	650
Maximum pressure	bar	10
	kPa	1000
Hoses minimum inside diameter	mm	16

Consumption for 1000 spots at 6 bar (600 kPa)		Pneumatic cylinder	
		<input type="checkbox"/> Standard Ø 125	<input type="checkbox"/> Optional Ø 125 x 2
Standard pneumatic circuit			
with maximum working stroke	Nm <sup>3</sup>	15,4	21,7
with 20 mm stroke and operating with maximum double stroke	Nm <sup>3</sup>	4,6	9,4
Pneumatic circuit with low force squeeze (optional)			
with maximum working stroke	Nm <sup>3</sup>	9,2	15,5
with 20 mm stroke and operating with maximum double stroke	Nm <sup>3</sup>	2,9	6

**2.5 COOLING CIRCUIT CONNECTIONS DATA**

Maximum water pressure	bar	4
	kPa	400
Hoses inside diameter - input	mm	16
Hoses inside diameter - output	mm	16
Minimum consumption for nominal power		
6121 – 6122 – 6123	l/min	10
6124 – 6125 – 6126	l/min	12

**2.6 ADDITIONAL FEATURES**

Item	6121	6122	6123	6124	6125	6126	
Net weight of the machine	kg	490	500	550	540	600	
Machine painting colour	<input type="checkbox"/> Grey RAL7032 <input type="checkbox"/> .....						
Aerial noise produced (Continuous acoustic pressure level produced; A weighed value)	dB(A)	75	75	77	76	76	78
Measurement position	h=1,60 m L=0,5 m						
Measurement conditions							
working stroke	mm	50	50	20	50	50	20
welding time	ms	440	440	180	400	400	160
welding current	kA	24	24	24	45	45	45
working rating	welds/min	6	6	15	6	6	15

## 2.7 MAIN WELDER FEATURES

- Medium frequency welder. In comparison with a traditional welder, it offers the following advantages:
  - High mains  $\text{Cos } \varphi$ .
  - Reduced load on plant primary electrical service.
  - Balanced load distribution on the three phases.
  - No effect of magnetic materials between arms on the welding current.
  - Reduced installation costs.
- Two-stage electric foot control for clamping and welding pieces only if correctly positioned.
- Pre-setting for additional double stage electric foot connection for the direct recalling of welding program no.2.
- Electrodes descent without pressure for set up and service.
- Lubrication free cylinder with chrome plated stem for heavy-duty works and long life.
- Water-cooled transformer, inverter, plates, electrode-holders and electrodes; transformers with epoxy resin coated windings.
- Adjustable double stroke with key control, adjustable antirotation device.
- Built-in compressed air filter unit and tank.
- Silencers for compressed air discharge.
- Two-hand safety control with timer for maximum safety, and removable key selector, standard on all models. The push buttons of the two-hand control are standard on projection models only (on request on spot welder models).
- Emergency push-button to stop the machine immediately.
- Automatic circuit breaker for protection.
- Flow-switch to prevent welding if water is not circulating (active either with recirculating water system or with city water).

### OPTIONS:

- 6130 - Valve for the automatic block of the cooling circuit when the welder is off.
- 6132 - Rotary selector for recalling the welding programs, placed on the welder frontal side.
- 6133 - Double stroke with pneumatic foot control instead of a key one. To be used only for spot welding when the working necessarily requires it.
- 6135 - Cylinder 1242 daN ( $\varnothing$  125 double stage) total stroke 100 mm.
- 6138 - Low-pressure squeeze for cylinder 736 daN.
- 6139 - Low-pressure squeeze for cylinder 1242 daN.
- 6140 - Proportional valve. Allows to adjust the working pressure directly from the control unit and to combine a proper pressure value to each program.

## 2.8 WELDING CONTROL TE600 DESCRIPTION

The TE600 is a microprocessor welding control unit for medium frequency resistance welders. The welding control includes a keyboard, a display and a removable security key. It is possible to program and to store up 63 different welding programs. All the programs can be recalled directly from the keyboard; 31 programs can be recalled from an external source by means of a PLC. Each program can assume all the configurations included between the simplest 4 times cycle, up to the most complex one, which can include the slopes, the pulses, the pre-welding, the post-welding, the forging and the minimum and maximum current limits.

### MAIN FEATURES

- 63 welding programs.
- 22 programmable parameters for every program.
- Constant current working, it allows to directly program the value of welding current. During the welding operation the current supplied is automatically kept at the set value.
- Measurement of the welding current, possibility to input control limits on the current value.
- Slope, pulses, pre-weld, and post-weld functions.
- Adjustment of the welding time in thousands of a second.
- Stepper function to compensate the electrode wear with programmable curve.
- Welds counter with possibility to program the number of welds to be carried out.

### PROGRAMMABLE PARAMETERS

PARAMETER	PARAMETER	RANGE VALORE
WORK MODE	WORKING MODE	IK
STROKE	DUAL STROKE MODE	SHORT
SQUEEZE 1	1 <sup>ST</sup> SQUEEZE TIME	01 – 99 cycles
SQUEEZE	SQUEEZE TIME	00 – 99 cycles
FORGING	FORGE DELAY	00 – 99 cycles
PRESSURE	WELDING PRESSURE	00.5 – 10.0
PRE-WELD	PRE-WELD TIME	0000 – 1000 ms
PRE-CURRENT	PRE-WELD CURRENT	001.0 – 120.0 kA
COLD 1	COLD TIME 1	0000 – 1000 ms
SLOPE UP	SLOPE UP TIME	000 – 500 ms
WELD1	WELDING TIME	0001 – 1000 ms
CURRENT 1	WELDING CURRENT	001.0 – 120.0 kA
COLD 2	COLD TIME 2	0000 – 1000 ms
NUMBER	IMPULSE NUMBER	0 – 5
WELD 2	SECOND WELDING TIME	0000 – 1000 ms
CURRENT 2	SECOND WELDING CURRENT	001.0 – 120.0 kA
COLD3	COLD TIME 3	0000 – 1000 ms
WELD 3	WELDING TIME 3	0000 – 1000 ms
CURRENT 3	WELDING CURRENT 3	001.0 – 120.0 kA
SLOPE DOWN	SLOPE DOWN TIME	000 – 500 ms
COLD 4	COLD TIME 4	0000 – 1000 ms
POST-WELD	POST-WELD TIME	0000 – 1000 ms
POST-POWER	POST-POWER CURRENT	001.0 – 120.0 kA
HOLD TIME	HOLD TIME	03 – 99 cycles
OFF TIME	DWELL TIME	00 – 99 cycles
CURR MIN.	MIN LIMIT IN CURRENT	001.0 – 120.0 kA
CURR MAX.	MAX LIMIT IN CURRENT	001.0 – 120.0 kA

For further information concerning TE600 see the relevant instruction manual.

### 3 INSTALLATION

These paragraphs are addressed to the specialized personnel in charge of both welder transport and installation. The welder dimensions diagram in the technical documentation booklet provides useful information for carrying out these operations.

#### 3.1 PLACE OF INSTALLATION

The welder must be installed in a position fulfilling the following features:

- In an inner place. The use of the welder in an open place is not foreseen.
- Room temperature included between 0 and 40 °C (If water is removed, storage is allowed down to 20°C below 0); 1000 m. maximum altitudes.
- In a well-ventilated area, free from dust, steam, and acid exhalations.
- The working place must be free from inflammable materials because the working process can produce spatter of melted metal.
- Around the welder there must be enough room to carry out both working and maintenance in a comfortable manner and without any risk.
- In a place with a suitable lighting system in comparison with the work to be carried out.
- The place of installation must necessarily be flat and the ground must be without unevenness, which can be dangerous during the working.

If the welder is used to carry out welding processes which can cause smoke exhalations, there must be installed a proper aspirator. The welder must be properly fixed to the ground through the proper holes placed on the welder basement. Do not install nearby the welder neither supporting tables nor equipment limiting the approaching to the devices and/or making inaccessible or ineffectual the safety devices.

#### 3.2 UNPACKING AND TRANSPORT

On receipt of the welder, verify the perfect integrity of the outer package; communicate to a responsible in charge possible anomalies, which should be noticed. Possible damages on the outer package should arise some doubts on the integrity of its content. Remove the package and visually verify the welder integrity. Check that the welder is equipped with all the standards components; immediately inform the manufacturer in case some components should lack. All the material forming the package must be removed according to the present environmental protection regulations.

The welder barycentre is high from ground. For this reason, the welder must be moved only by means of the proper attachment placed on the unit upper side. Consider to the welder weight stated on the "TECHNICAL FEATURE" paragraph.

#### 3.3 PNEUMATIC INSTALLATION

For a correct compressed air supply to the welder, it is necessary either a centralised system or a compressor capable of supplying dry air cooled within the maximum pressure and in the quantity stated in the paragraph "Technical Features". Pay attention to the hoses minimum diameter stated in the same paragraph.

In case the line is subject to great pressure variations, it is advisable to supply the welder by means of a tank of at least 50-100 litres equipped with a gauge/manometer supplied by means of a one-way valve.

The machine is equipped with a filter unit, whose moisture must be discharged periodically. Periodically discharge also the moisture eventually present in the built-in small air tank, by means of the tap placed on the bottom of the tank itself.

The welder has been assembled by using components that do not require lubrication. The insertion of a lubricator in the equipment causes no problems to the welder; nevertheless, pay attention to the fact that this brings the emission of oil mist in the environment.

### **3.4 COOLING WATER CONNECTION**

For a correct cooling of the welder it is necessary clean water at a maximum temperature of 30°C at the quantity stated on the paragraph "Technical features". When connecting the unit to the water line check for dirt or packing scraps in the hoses and connect the supply to the inlet, and the drain to the outlet, this to allow that still cool water immediately reaches the parts of the welder most subjected to heating.

Different cooling circuit systems are available: with city supply water, with recirculating water, with heat exchanger (air-water) and with refrigerator. If the circuit is with city supply or refrigerator and you are working in presence of high humidity, we suggest avoiding the use of low temperature water, as this could produce moisture inside the machine. In presence of hard water it is necessary to install a water softener at the inlet hose, this to avoid that deposits obstruct or reduce the water channels in the welder causing damages. If the machine is operated in a recirculating water supply, the water softener must be placed on the supply of the tank, an insertion before the machine generates damages.

### **3.5 ELECTRICAL INSTALLATION**

The welders described in this manual are designed only for professional purposes in industrial environments use. They must not be installed on public low voltage network, which supplies domestic premises. This can cause electromagnetic interferences.

Specialized personnel, aware of all safety rules, must carry out installation.

As this unit can be supplied for different power supply versions, before connecting the unit to the power line, check if the voltage shown in the features plate corresponds to the one of your power supply.

Consult the "technical features" paragraph to determine cable section to be used, according to their length. On this paragraph you find also the values of fuses, which must be placed on the welder, supply input. Fuses must be delayed type. Connect the machine to earth by using a cable having the same section of the mains cable. In order to facilitate the maintenance operation, we recommend you to supply the welder by means of a mains disconnecting switch. The welder has not been designed for different voltages supply. If a voltage change is necessary consult your supplier for the replacement of required parts and new set ups.

## 4 WORKING PROCESS

The welder has been designed for being used by an operator placed in front of the unit and working on the same working ground on which the welder is installed.

When arranging the working place, always follow the following instructions:

- Use a well-ventilated area, free from dust, steam, and acid exhalations.
- The working place must be free from inflammable materials because the working can produce spatter of melted metal.
- Around the welder there must be enough room to carry out both working and maintenance in a comfortable manner and without any risk.
- If the welder is used to carry out welding processes which can cause smoke exhalations, there must be installed a proper aspirator.
- Do not install on the welder neither supporting tables nor equipment, which either limit the approaching to the devices or make inaccessible or ineffectual the safety devices.





When switching on the welder, besides triggering the main switch, it is necessary to press also the control unit RESTART button. This device enables the welding control and supplies the service circuit. **Before pressing the button, check that this does not cause damages to both people and tools.**

Before starting the working process, carry out the following adjustments:


- 1 - Mechanical set up
- 2 - Electrode force adjustment
- 3 - Welding parameters adjustment
- 4 - Calculation of the maximum welding rating

The following paragraphs carefully explain these different phases.

Before starting the working process:

- Check that all the safety instructions have been operated.
- Check that the correct device has been selected (by means of the TWO-HAND/FOOT CONTROL ). Each time the type of production allows it; it is compulsory to use the unit by means of the push-buttons control device. The control device, which is not employed must be detached and removed from the working place. Remember that on the control unit there is 2 positions removable key-switch preventing the operator from freely modifying the working conditions (with the consequent risk of altering the safety conditions); for further information, refer to the control unit instruction manual.
- Additional foot-control (which is supplied on request): if it is not used when working, disconnect it and remove it from the working place.
- Check that the automatic cycle is inserted only when it is really used.
- Check that the pneumatic circuit is supplied.
- Check the correct functioning of the control devices; at the first stage, the foot control must have a 10-12 mm stroke.
- Carry out some test cycles in order to verify both the cycle correctness and the operating speeds. These tests should be carried out without current circulation by means of the control device WELD/NO WELD  placed on control unit TE600.

Before starting the welding process, check the welding conditions (time, pressure, etc.). If you are operating spot welding, use two off-cuts of the sheet to weld, carry out two spots at the same distance used during the production, then remove the first and check the second: the spot is correct when the pulling test causes the coming out of the weld nugget with the hole of a sheet, and the twist test shows a pure area without porosity or causes the coming out of the nugget. Similar considerations and similar tests should be carried out also for projecting welding.



During the production it is advisable to monitor those parameters that can alter the working conditions and thus the welds quality. If you are operating spot welding, always monitoring the electrodes which must always be clean, without any deformations and must have the proper diameter according to the work to be carried out. Check that there are not strong changing in the welder supply pressure that could modify the force on the electrodes and thus the welding quality.

Do not use sealing products to remove water losses on the electrodes conic connection. To facilitate the electrode removal and to prevent from both cone seizure and water losses, use high conductivity grease similar to the standard one.

The cooling water must circulate inside the welder for a few minutes after having completed the production in order to allow the welder cooling. To prevent from both losses and moisture deposits, do not leave the cooling circuit open when the unit is not used.

Electrodes must not be used to force the clamping of the pieces to weld.

We recommend you to notice the adjustments carried out for each type of piece. In order to make it easier, a specific table has been added at the end of this manual.


## 4.1 MECHANICAL SET UP

### Spot welding electrodes adjustment.

With control unit set to NO WELD, the start device is activated; with the electrodes touching, contact between electrodes should be uniform. If required, carry out the adjustment. It is advisable to adjust electrodes with a fine file or with sand paper. In case of steel welding, the electrodes diameter should correspond to the values shown on the following table.

Sheet thickness	mm	0,5	0,8	1	1,5	2	2,5	3	3,5	4
Required diameter	mm	4	4,5	5	6	7	7,5	8,5	9,5	11

Suggested electrode tip angle is 120 degrees. If the thickness of the two plates is different the electrode must have the diameter corresponding to the one required by the plate to which it gets in touch.



A too small diameter in comparison with the thickness to be welded produces spatter of melted material, sheets over mark, low spot quality. If the electrode diameter is too large, longer welding times are necessary, causing a higher heating of the welder and a shorter life of electrodes. For aluminium spot welding we suggest to use spherical electrodes, radius value varies according to the thickness to be welded and the kind of quality required.

### Projection welding tools adjustments.

When assembling the equipment on the projection plates, carefully follow the following instructions:

- Adjust the components in order to have them perfectly combine. To facilitate this operation, on the welding cylinder left side there is a hand-operated valve which enables the head descent by discharging the backpressure.
- Welding force must be equally distributed on the different welding spots; for this reason, tools must be parallel when the desired welding force is applied to them.
- Adjust stroke to the minimum value to increase the tool follow up.


## Working Stroke Adjustment

Adjust working stroke as short as possible to get:


- 1) Higher productivity.
- 2) Faster pressure rise time on the pieces to weld.
- 3) Higher follow up.
- 4) Higher working precision.
- 5) Reduced labour accident possibility.
- 6) Reduced air consumption.
- 7) Reduced noise.

The working stroke can be adjusted either by moving the lower console or, if the unit is spot welding operated, by moving one of the two electrode-holders.

To adjust the lower console height, first slacken nuts 102, then slacken screws 101. Carry out the desired adjustment by means of the hydraulic jack, then tighten home first screws 101, then nuts 102.



The stroke adjustment must be carried out in order to avoid that the cylinder reaches the end of the stroke, limiting or cancelling by doing so the force on the piece. Remind that both electrodes and equipment wear increases the working stroke.



When operating large-sized pieces spot welding it can be necessary to use a high stroke to be able to insert pieces among the electrodes. To allow the use of a reduced stroke even when operating in this way, this unit is equipped with a control device called "double stroke". A key switch, placed on the welder and marked with the symbol hereby shown, enables to select two different electrodes gaps: the working stroke and the large gap used to position the

piece. When the double-stroke is not used, the corresponding control key must be removed in order to avoid that its use causes risks.

On request, on some welders it is assembled a foot-control device as the operator, who must hold the piece to weld, is not able to control also the key switch.

It is possible to adjust the double stroke by means of the proper hand-wheel placed on the cylinder. Always carry out this operation keeping the double stroke disabled.

## 4.2 ELECTRODE FORCE ADJUSTMENT

The following paragraphs show how to adjust both the standard pneumatic circuit, and the optional one with a low force squeeze. The welding force must be selected taking into consideration both tables and personal experience, and in relation to the sheets thickness, the desired spot quality, etc.



**Always adjust by keeping the welding control unit on “NO WELD” in order to avoid any risk caused by a wrong adjustment. Always carry out “NO WELD” cycle tests before starting the welding process.**

An excessive electrodes force can cause:

- welding over marks;
- possible electrodes short life;
- weak welding or false welding due to a reduction of contact resistance, which allows the current to pass through without bringing the piece to the melting temperature.

An insufficient force on electrodes can cause:

- spatter of melted material;
- stuck weld of the pieces on the electrode;
- welding with a disagreeable outside surface.

If the welding to be carried out requires low or precise force values, it is advisable to use a dynamometer.

### 4.2.1 STANDARD PNEUMATIC CIRCUIT ADJUSTMENT

The electrodes force adjustment is carried out by means of the pressure control REG1. This carries out the pressure P1 adjustment, (displayed by pressure gauge MAN1), modifying the welding force.

Upon demand, it is possible to have a proportional valve EVP to adjust the working pressure directly from the control unit and to combine a proper pressure value to each program. Assures constant and accurate working pressure.


The reached force values, concerning the different pressure values showed on the pressure gauge, are listed in the following table:

PRESSURE		CYLINDER Ø125 (STANDARD)	CYLINDER Ø125 × 2 (OPTION 6135)
bar	kPa	FORCE in daN	FORCE in daN
0,5	50	61	103
1	100	122	207
2	200	245	414
3	300	368	621
4	400	490	828
5	500	613	1035
6	600	736	1242

The head descent speed adjustment is carried out by means of the flow regulator RFL2; the rise speed adjustment is carried out by means of the flow regulator RFL1. The flow regulator RFL3 must be used in order to carry out the double stroke descent speed adjustment.

#### 4.2.2 LOW FORCE SQUEEZE PNEUMATIC CIRCUITS ADJUSTMENT (OPTION)

On request, the welder can be equipped with a pneumatic circuit enabling the low force squeeze, useful especially for projection welding and with light alloys. The pneumatic circuit functioning varies according to the used pneumatic cylinder:



The electrodes force adjustment is carried out by means of the pressure regulator REG1. This carries out the pressure P1 adjustment, displayed by pressure gauge MAN1, modifying both the welding and the squeeze force.

Upon demand, it is possible to have a proportional valve EVP to adjust the working pressure directly from the control unit and to combine a proper pressure value to each program. Assures constant and accurate working pressure.

The reached force values, concerning the different pressure values showed on the pressure gauge, are listed in the following table:

PRESSURE		CYLINDER Ø125 (STANDARD)	CYLINDER Ø125 × 2 (OPTION 6135)
bar	kPa	FORCE in daN	FORCE in daN
0,5	50	61	103
1	100	122	207
2	200	245	414
3	300	368	621
4	400	490	828
5	500	613	1035
6	600	736	1242

The head descent speed adjustment is carried out by means of the flow regulator RFL2; the rise speed adjustment is carried out by means of flow regulator RFL1. The flow regulator RFL3 must be used in order to carry out the double stroke descent speed adjustment.

### 4.3 WORKING PROGRAM ADJUSTMENT

This operation consists in choosing the welding parameters and entering them directly on the welding control. Select parameters from table or personal experience taking into consideration the plate thickness, the welding desired quality etc..

Use short weld time to reduce the electrodes heating and to increase their life, avoiding at the same time oxidation on the contact surfaces. The best quality welds are obtained by using times as short as possible with high current and electrode force.


Notice that when operating pieces with different thickness, the welding parameters to be used are those referring to the lower thickness.

This welder can operate under two different working modes: single cycle and, by using only the foot device, automatic cycle. The adjustment instructions are stated on the welding control unit instruction manual. When working in automatic cycle, as long as the start-cycle control device is activated, the welder will repeat welding cycles at the settled OFF time. In single cycle, even though the start device is kept activated, the welding unit will stop after having carried out a single cycle; to carry out the next one, it is necessary first to release the device and then press it once again. **To prevent from any risk, use the automatic cycle only when it is really necessary; it must not be activated when it is not used.**

On welders equipped with a rotary selector enables to select the required welding program. By adjusting the selector on "0", the machine will work with the program selected on the control unit.

#### **Welders equipped with low force squeeze:**

Use a 1° SQUEEZE time long enough to allow the electrodes to reach the pieces to be welded before the welding force is activated.



Adjust SQUEEZE at a value high enough to allow the air coming out from the cylinder lower chamber (reaching, by doing so, the correct welding force) before the welding process starts.

#### 4.4 CALCULATION OF THE MAXIMUM WELDING RATING

Before starting the production, it is necessary to verify that the welding rating does not exceed the maximum limit allowed by the welder in comparison with the set welding conditions (time and current), otherwise causing a too high over heating.

The welder maximum welding rating is the function of the thermal load applied to the welder itself, depending from both the used time and welding current and from the numbers of weld for unit of time. With these different parameters it is possible to define the  $I_{th}$  value, which is the "equivalent thermal current at the duty cycle of 100%". Its value is calculated as follows:

$$I_{th} = \sqrt{\frac{\text{number of welding cycles per minute} \times (\text{welding current in kA})^2}{60000}}$$

**The resulting value must be lower than the welder maximum one. On the contrary, it is necessary to reduce the welding rate.**

When different welding programs are used or when using a welding cycle with pre-weld or post-weld, the value of these different currents must be calculated separately, then added in order to obtain the equivalent total value.

*Examples:*

Example 1: Cycle simple

Welding current = 41000 A

Welding time = 18 ms

5 welds per minute

$$I_{th} = \sqrt{\frac{(360 \times 5) \times (41000)^2}{60000}} = 7101A$$

Example 2: Cycle with pre-weld

Welding current = 30000 A

Welding time = 360 ms

Pre-current = 11000 A

Pre-weld = 120 ms

8 welds per minute

$$I_{th1} = \sqrt{\frac{(360 \times 8) \times (30000)^2}{60000}} = 6573A$$

$$I_{th2} = \sqrt{\frac{(120 \times 8) \times (11000)^2}{60000}} = 1391A$$

$$I_{th} = \sqrt{I_{th1}^2 + I_{th2}^2} = \sqrt{(6573)^2 + (1391)^2} = 6718A$$

The post-welding current can be calculated in the same mode.

Example 3: Cycle with pre-weld and post-weld

Welding current = 23000 A

Welding time = 280 ms

Pre-current = 15000 A

Pre-weld = 140 ms

Post-current = 9500 A

Post-weld = 80 ms

8 welds per minute

$$I_{th1} = \sqrt{\frac{(280 \times 8) \times (23000)^2}{60000}} = 4444A$$

$$I_{th2} = \sqrt{\frac{(140 \times 8) \times (15000)^2}{60000}} = 2049A$$

$$I_{th3} = \sqrt{\frac{(80 \times 8) \times (9500)^2}{60000}} = 981A$$

$$I_{th} = \sqrt{I_{th1}^2 + I_{th2}^2 + I_{th3}^2} = \sqrt{(4444)^2 + (2098)^2 + (981)^2} = 5011A$$



Example 4: Welds carried out with different welding programs.

2 welds per minute with:

Welding current = 30000 A

Welding time = 360 ms

$$I_{th1} = \sqrt{\frac{(360 \times 2) \times (30000)^2}{60000}} = 3286 \text{ A}$$

6 welds per minute with:

Welding current = 22000 A

Welding time = 240 ms

$$I_{th2} = \sqrt{\frac{(240 \times 6) \times (22000)^2}{60000}} = 3408 \text{ A}$$

$$I_{th} = \sqrt{I_{th1}^2 + I_{th2}^2} = \sqrt{(3286)^2 + (3408)^2} = 4734 \text{ A}$$

## 5 SAFETY RULES

For a safe welder use, specialized personnel following all the instruction stated on the "INSTALLATION" chapter must carry out the installation.

The welder maintenance must be carefully carried out following all the safety instruction stated on the "MAINTENANCE" chapter. In particular, notice that the electrodes maintenance must be carried out with the welder switched off.

Only trained personnel must operate the welder; in any case, **users operating the welder must be aware of the possible risks and must have both read and understood this manual.**

Only authorised personnel can carry out the welder adjustment. The welder adjustments affect the operative safety so much so that only qualified personnel must carry them out.

Carefully follow the instruction stated on the "WORKING PROCESS" chapter.

It is forbidden to have more people working on the welder at the same time.

No admittance allowed to the working area to people other than the operator.

The welder main risk is the squashing of the upper limbs caused by the moving of the mobile components: electrodes, electrode-holder, projection plate, tools, etc. For this reason, it is necessary to pay great attention and to follow all the instructions stated on this manual. In particular:

- Use the Two-Hands control each time that it is possible.
- Adjust the working stroke to the minimum allowed value.
- Avoid working with the hands nearby the mobile components.
- Use pliers or equipment allowing the positioning of the pieces by keeping the hands far from the mobile components. This equipment, which is often made of either insulating or non-magnetic materials, allows improving both productivity and mechanical positioning precision of both pieces and welds.
- When possible, place screens allowing to insert into the dangerous area only the pieces to be welded.
- Use sleight systems allowing to load and unload the pieces out of the welding area.

In case of any water leakage entering the welder, immediately stop the electrical supply.

**Notice that these types of machines generate strong magnetic fields attracting metals and damaging watches, magnetic cards and magnetic data storage media. Since these magnetic fields can affect pacemakers, the wearers must consult their doctor before approaching to the welding area.**

**The personnel must wear both safety glasses and gloves. Avoid wearing rings, metal watches and clothes with either metal accessories or components.**

When operating heavy working, high thickness and pieces with a difficult coupling, wear safety shoes and aprons, and use protection screens to protect the operator from possible split of melted materials.

The safety shoes must be worn each time the pieces, because of their shape or weight, bear risks requiring them.

Keep the nearby welder working area free from flammable materials. In case the material to be welded produces either smoke or exhalations, install a proper aspirator.

The noise produced by the welder depends mainly from the adjustments. To reduce the noise:

- Adjust the working stroke to the minimum value allowing carrying out the operation.
- Work keeping the double stroke activated.
- Adjust both the head rise speed and descent speed to low values.
- Periodically check the silencers.

In addition to the information stated on this chapter, always operate in accordance with all the relevant regulations in force.

## **6 ACCESSORIES AND SPARE PARTS REQUEST**

When ordering accessories, spare parts or expendable material please state: type of machine, year of manufacture, serial number, the voltage and frequency.

Available accessories:

70379 - Additional welding foot-control with direct recalling of welding program n°2, equipped with connection plate for connecting to the main foot-control. Cable L=1,4m. for welding 6121-6122-6124-6125.

70462 - Additional welding foot-control with direct recalling of welding program n°2, equipped with connection plate for connecting to the main foot-control. Cable L=2,4m. for welding 6123-6126.

70320 - Two-hand safety control with timer for maximum safety The push buttons of the two-hand control are standard on projection models only (on request on spot welder models).

71379 - Serial interface RS232, enabling the connection with a serial printer or a personal computer for production data recording.

71380 - Serial interface RS485, interface for network connection of welding control units. Allows remote programming and production data recording.

Expendable materials:

8701 - Straight electrodes, a pair.

8702 - Flat electrodes, a pair.

8703 - Offset electrodes, a pair.

8704 - Oversize diameter flat electrodes, a pair.

8705 - Angled offset electrodes, a pair.

8706 - Bent electrodes, a pair.

8726 - Chromium zirconium copper alloy  $\varnothing$  22 L=750mm.

**WARNING.** On request, the welding unit can be supplied with a taper ratio other than standard. The listed items refer to the standard taper  $\varnothing$  19.05 mm 3/4" 2° 30' BS 807.

## 7 MAINTENANCE

### 7.1 ORDINARY MAINTENANCE

This chapter states the necessary maintenance operations to be carried out for:

- 1) keeping the welding unit safe operating and preserving its efficiency;
- 2) avoiding the most common causes of wrong working worsening the welding quality.

#### GENERAL WARNINGS



**Always disconnect both electrical and pneumatic supply before carrying out the following maintenance operations.**

- Keep always the screws of arms, electrode holder, plates and rigid/flexible connections well tightened.
- Remove oxidation from secondary circuit with fine sand paper.
- Periodically lubricate (at least every 6 months) with some drops of oil the cylinder stem after having removed the grub screw on the piston base.
- Lubricate with grease the antirotation device; if necessary, adjustment can be made by means of both screws and nuts placed on the sides of the piston.
- Keep welder clean from dirt and metal scraps attracted by magnetic field generated by the welder during operation.
- Neither washes the welding unit with jets of water, which could enter it, nor use strong solvents, thinner, nor benzine that could damage either painting or the machine plastic components.

#### ELECTRODES MAINTENANCE



**Electrodes maintenance must be carried out with the welder switched off.**

- When operating, the electrodes must be kept clean and their diameter must be kept suitable for the work to be carried out. Too worn electrodes must be replaced.
- When replacing electrodes, check that the tube bringing water to the electrode inside stops at a few mm from the bottom of the electrode hole.
- Do not use sealing products to remove water leakage on the electrode taper. To facilitate the electrode removal and to prevent from both taper seizure and leakage, use high conductivity grease similar to the standard one.

#### PNEUMATIC CIRCUIT MAINTENANCE



**Only specialized personnel trained to accomplish it under safety conditions must carry out pneumatic circuit maintenance. When possible, maintenance must be carried out with the welder switched off and disconnected from the pneumatic supply, with the circuit free from left air. Pay attention to the welding cylinder descent following this operation.**

- In case of air leakage, immediately stop operating and remove it.
- Periodically drain the moisture from the filter group.
- Periodically discharge also the moisture eventually present in the built-in small air tank by means of the tap placed at the bottom of the tank itself.
- Check pressure gauges calibration.
- Check the status of both compressed air and corresponding connections.

## COOLING CIRCUIT MAINTENANCE



**Only specialized personnel trained to accomplish it under safety conditions must carry out cooling circuit maintenance. When possible, maintenance must be carried out with the welder switched off and disconnected from the pneumatic supply, with the circuit free from left air.**

- Check that cooling water circulates freely and in the required quantity and that the input temperature is included within 10 and 30°C.
- Check the status of both water hoses and corresponding connections.
- If, during the winter time, the welder must be stored up in cool rooms, it is necessary to carefully drain first the cooling circuit to prevent from possible damages caused by frozen water.

## ELECTRIC CIRCUIT



**Only specialized personnel trained to accomplish it under safety conditions must carry out electric circuit maintenance. Disconnect electric mains before carrying out the following instructions, as discharges coming from the supply can be lethal.**

- Periodically check ground efficiency.
- Periodically check the safety device efficiency (emergency push-button, two-hand safety control, flow switch, etc.).
- Often check both the status and the proper working of the control devices and of the corresponding connecting cables.

**7.2 EMERGENCY CONDITIONS WARNINGS.**

In case of emergency, push the emergency push-button totally disconnecting the welder from the electric mains. This push-button is placed close to the welding cylinder and it is red on a yellow background. Once it has been activated, before switching on the welder it is necessary first to rotate this push-button to disconnect it; on the contrary, it will be impossible to activate the main switch.

If their take place water leakage, which could enter the welder, immediately disconnect the electric supply.

In case of fire do not use water but proper fire extinguishers.

Only qualified personnel trained to accomplish all the machine necessary tests must carry out the placing in service of the welder after an emergency condition.

Remember that the emergency push-button is a safety device that has been designed and weighed specifically for this function. Do not use it for the normal switching off of the welder.

### 7.3 EXTRAORDINARY MAINTENANCE

This chapter states the maintenance operations to be carried out in case of:

1. lowering of the welder performances;
2. welder wrong operating;
3. welding faults.

#### 7.3.1 LOWERING OF THE WELDER PERFORMANCES



**Only specialized personnel equipped with the proper instruments and trained to accomplish it under safety conditions must carry out extraordinary maintenance. When possible, the welder must be disconnected from both pneumatic and electric supply.**

If performances are lower than expected, check:

- That, during welding, line voltage drop is lower than 15%.
- That the supply cables section is adequate.
- That the electrodes diameter is appropriate for the work to be carried out.
- That cooling water circulates in the required quantity.
- That welding pressure shown by the pressure gauge is adequate for the work in process.
- That the pressure gauges work properly.

#### 7.3.2 TROUBLESHOOTING



**Only specialized personnel equipped with the proper instruments and trained to accomplish it under safety conditions must carry out troubleshooting. When possible, disconnect both electric and pneumatic supply.**

In case of a wrong operating welder, use the following table for finding out both fault cause and remedy.

FAULT	CAUSE	REMEDY
Main switch does not close.	Emergency push-button activated.	Rotate emergency push-button to deactivate it.
	No mains voltage or mains voltage inadequate to operate coil minimum voltage.	Check that mains voltage is correct on all the three phases.
	Fuses FU4-FU5 blown.	Replace them.
	Faulty switch.	Replace it.
Main switch closes, but control unit does not switch on. Control unit led ON keeps off.	Fuses FU1-FU2 blown.	Replace them.
	Either connectors or cables disconnected.	Check.
	Control unit fuse blown.	Replace it (see control unit use manual)

FAULT	CAUSE	REMEDY
Main switch closes, but control unit does not switch on. Control unit led ON is on.	Inadequate mains voltage	Check.
	Faulty control unit.	Replace it.
When operating the welding units blocks the cycle and the head rises up.	Excessive voltage drop.	Check that voltage drop is lower than 25%. On the contrary, check that supply cables section is adequate to their length.
By pressing foot-control device the electrode don't descend, the display shows "FLOW-SWITCH / PRESSURE-SWITCH ACTIVATED".	Inadequate or no water circulation, or insufficient pressure air. Flow Switch SF1 activated.	Check that water circulates in the required quantity. Eventually calibrate the Flow-switch.
The display shows "BOOSTER NOT READY".	Thermostat placed on booster or thermostat placed on welding transformer activated.	Check that water circulates in the required quantity and/or check the correct thermostat working.
By pressing foot-control device the electrode descends but does not weld. Electrode rises up only when releasing the foot-control.	The foot-control device enables the micro-switch START but not the AUXILIARY one. The control unit AUXILIARY led switches on when pressing foot-control and keeps on until it is released.	Check both the foot-control connections and corresponding micro-switches. Check cams positioning inside the foot-control.
The welder carries out the welding cycle without current circulation. Control unit CURRENT led is off during the welding cycle.	WELD/NO WELD control device set to NO WELD.	Set to WELD (led on)
	Faulty control unit.	Replace it.
Welding cycle carried out with reduced current circulation.	Faulty contact in the secondary circuit.	Check and tighten all the secondary connections. Do not forget the electrode and electrode-holder connection.
No electrode descent. Welding control unit led EV1 is on.	Lack of compressed air.	The corresponding manometer shows it (MAN5). Operate.
	Welding pressure inadequate.	The corresponding manometer shows it (MAN1). Increase it by means of the pressure regulator.
	Broken connection between the control unit and the solenoid valve.	Check.
	Faulty solenoid valve EV1.	Replace it

FAULT	CAUSE	REMEDY
Too slow or not uniform descent.	Inadequate welding pressure.	It is shown by the proper pressure gauge (MAN 1). Adjust it correctly by means of the pressure regulator (REG1).
	Faulty Flow-switch RFL2 adjustment.	Adjust it correctly.
Low electrodes welding force.	Low welding pressure.	It is shown by the proper pressure gauge (MAN 1). Adjust it by means of the welding pressure regulator (REG 1).
	The backpressure is not removed before welding (optional pneumatic circuit).	Check that EV2 operates correctly and that the control unit corresponding led lights.
The upper electrode does not rise up.	Low backpressure.	Correctly adjust the working pressure (REG 1).
	Too closed flow regulator RFL1	Correctly adjust it.
	Faulty solenoid valve EV2 (optional pneumatic circuit).	Replace it.
Spots or electrodes overheating.	Insufficient cooling.	Check that water circulates in the required quantity and at a low temperature.
	Too high welding current or welding time.	Reduce them.
	Too high post-heating time and/or current.	Change them.
Electrodes reduced life.	Insufficient cooling.	Check that water circulates in the required quantity and at a low temperature.
	Under-seized electrode in comparison with the work to carry out	Check both size and contact diameter.
Secondary connections reduced life.	Insufficient cooling.	Check that water circulates in the required quantity and at a low temperature.
	Heating caused by an inadequate clamping of the flexible connection.	Carefully tighten the clamping screws.
	Too high heating caused by a too high welding rate	Reduce it.

### 7.3.3 REMEDIES FOR WELDS IMPERFECTIONS.

This chapter has been introduced in order to facilitate the troubleshooting of the most common imperfections caused by a wrong adjustment. Notice that each one can be caused by different causes as there are many parameters affecting the welding process. The following table specifically refers to low carbon steel spot welding, but, with the due considerations, it can be useful also for other applications.

FAULT	POSSIBLE CAUSE	POSSIBLE REMEDY
Weak welding	Low welding current.	Increase it.
	Low welding time.	Increase it.
	Too high electrodes force.	Reduce pressure.
	Lacking electrodes maintenance or too high electrodes diameter.	Clean and line up the electrodes, restore their dimensions.
	Faulty pieces contact.	Increase the electrodes force.
Spatter of melted material	Paint or dirt among pieces.	Clean the pieces.
	Inadequate electrodes cooling.	Check the cooling circuit.
	Faulty pieces contact or pieces and electrodes faulty contact.	Increase the electrodes force by increasing pressure.
	Too high welding current.	Reduce it.
	Too high welding time.	Reduce it.
	Too small electrodes diameter.	Adjust diameter to the value shown on the table.
	Inadequate welding force.	Increase pressure.
	Electrodes faulty clamping of the pieces.	Check stroke.
Burned welds or welds showing either craters or fissures.	Too high welding current.	Reduce it.
	Inadequate welding force.	Increase welding pressure.
	Oxidised pieces to weld.	Clean them by means of emery paper.
	Faulty pieces contact or pieces and electrodes faulty contact.	Increase electrodes force.
	Faulty pieces lining up.	Correct it.
	Electrodes tips deformations.	Restore them to the correct seize.
Pieces stuck weld on the electrode	Too high welding current.	Reduce it.
	Inadequate electrodes diameter.	Restore it to the correct dimensions.
	Inadequate welding force.	Increase the welding pressure.

## 8 ENCLOSURES

### 8.1 WELDING TABLES

In order to facilitate the search for the best welding conditions, we have herewith inserted the following tables stating the approximate adjusting values. Notice that the same weld can be carried out under different working conditions, so much so that the following data are not binding ones.


#### Low carbon steel spot welding

##### Welding class A

Thickness a mm	Spots minimum distance mm	Minimum overlap- ping mm	Electrodes		Electrodes force daN	Welding current kA	Welding time cycles	Obtained nugget d1 mm
			D min mm	d max mm				
0.25	6	9.5	9.5	3	90	4	4	3
0.5	9.5	11	9.5	4.5	136	7	5	4
0.75	12.5	11	9.5	4.5	181	8	7	5
1.0	19.5	12.5	13	6.5	225	9.5	8	5.5
1.25	22.5	15	13	6.5	294	10.5	10	6
1.5	27	16	13	6.5	362	12	12	6.5
2.0	35	18	16	8	498	14	18	7.3
2.5	42	19	16	8	590	15.5	22	8.3
2.8	48	21	16	9	725	17.5	24	9
3.2	50	23	22	9	820	19	25	10

##### Welding class B

Thickness a mm	Spots minimum distance mm	Minimum overlap- ping mm	Electrodes		Electrodes force daN	Welding current kA	Welding time cycles	Obtained nugget d1 mm
			D min mm	d max mm				
0.25	6	9.5	9.5	3	60	3.6	5	3
0.5	9.5	11	9.5	4.5	90	5	8	4
0.75	12.5	11	9.5	4.5	120	6.4	13	5
1.0	19.5	12.5	13	6.5	160	7.5	18	5.5
1.25	22.5	15	13	6.5	200	8.3	20	6
1.5	27	16	13	6.5	240	9	24	6.5
2.0	35	18	16	8	324	10.5	30	7.3
2.5	42	19	16	8	370	11.5	37	8.3
2.8	48	21	16	9	470	12.5	42	9
3.2	50	23	22	9	550	13.5	50	10
4.0	68	32	25	11	640	14.4	75	11.5





**Stainless steel 18/8 spot welding**

Thickness a mm	Spots minimum distance mm	Minimum overlapping mm	Electrodes		Electrodes Force daN	Welding current		Welding time cycles	Obtained nugget d1 mm
			D min mm	d max mm		* kA	** kA		
0.2	5	5	5	2.5	90	2	2	3	1.4
0.3	6	6	6	3	120	2.1	2	3	1.4
0.4	8	6	6	3	150	3	2.5	4	2.2
0.5	8	8	6	4	180	4	3.2	4	2.5
0.6	11	10	10	4	235	5	4.1	4	3
0.8	12	10	10	5	295	6	4.8	4	3.3
1	16	11	10	5	410	7.8	6.3	4	4
1.2	20	12	12.5	6	545	9.5	7.5	7	4.8
1.4	22	14	12.5	6	620	10.3	8.3	9	5.3
1.6	25	16	12.5	6	680	11	9	9	5.6
1.8	28	16	16	6	770	12.3	10	10	6.3
2	32	18	16	7	860	14	11	12	7
2.5	35	20	19	8	1090	15.7	12.7	13	7.2
3	50	22	19	10	1500	18	15.5	17	7.65

\* for stainless steel with tensile strength up to 100 kg/mm<sup>2</sup>



\*\* for stainless steel with tensile strength over 100 kg/mm<sup>2</sup>



**Crossed rods welding of cold drawn low carbon steel**

Rod diameter mm	Welding time cycles	Set-down 15%		Set-down 30%	
		Electrodes Force daN	Welding current kA	Electrodes Force daN	Welding current kA
1.6	4	45	0.6	68	0.8
3.2	8	56	1.8	117	2.6
4.8	14	160	3.3	270	5
6.35	19	260	4.5	380	6.7
8	25	415	6.2	650	9.3
10	33	495	7.4	925	11.8
11	42	630	9.3	1300	13.8
12.5	50	765	10.3	1530	15.8

N.B. In the welding of reinforced concrete rods there are cases in which with the same parameters you can weld different diameters, much higher.



$$\text{SET-DOWN} = \frac{A - B}{A} \times 100$$


**Aluminium spot welding**

*Welding Class A*

Thickness a mm	Electrodes force daN	Welding current kA	Welding time cycles	Electrodes		Obtained nugget d1 mm
				D mm	R mm	
0.5	180	18	5	16	50	3.5
0.75	230	24	6	16	50	4.0
1.0	250	30	7	16	50	4.5
1.5	320	35	9	19	100	5.5
2.0	400	40	10	19	100	6.5
2.5	520	49	11	19	100	7.5
3.0	600	58	12	25	100	8.5

*Welding class B*

Thickness a mm	Electrodes force daN	Welding current kA	Welding time cycles	Electrodes		Obtained nugget d1 mm
				D mm	R mm	
0.5	140	16	6	16	50	3.0
0.75	160	18	7	16	50	3.5
1.0	180	21	8	16	50	4.0
1.5	240	25	10	19	50	5.0
2.0	280	29	12	19	50	6.0
2.5	340	33	13	19	50	7.0
3.0	370	36	14	25	50	8.0



**Projection welding of low carbon steel**

*Projections dimensions*


Thickness a mm	Projection		Minimum distance between projections mm	Minimum overlapping mm
	Diameter d mm	Height h mm		
0.5	2.3	0.6	10	7
0.75	2.3	0.6	10	7
1.0	2.7	0.8	13	10
1.5	3.8	1	19	13
2.0	4.6	1.2	22	13
2.5	6	1.4	30	19
3.0	6.8	1.4	40	21

*Welding parameters*

Thickness a mm	Single projection			1-3 projections (data for each projection)			3 or more projections (data for each projection)		
	Time cycles*	Current kA**	Force daN	Time cycles*	Current kA**	Force daN	Time cycles*	Current kA**	Force daN
0.5	3	4400	68	5	3850	68	5	2900	36
0.75	3	5500	88	5	4450	68	7	3300	45
1.0	4	8000	150	8	6000	90	12	4300	70
1.5	8	10300	250	16	7650	166	20	5400	150
2.0	12	11850	365	24	8850	240	29	6400	215
2.5	15	14100	550	30	10600	370	40	8300	330
3.0	18	14850	680	37	11300	450	50	9200	400

\* Based on 50Hz supply networks.

\*\* Starting values.



## 8.2 PRODUCTION FORM FACSIMILE

## FIRM DATA

Firm	Department
------	------------

## WELDER DATA

Welder model	Number
Welding transformers connecting positioning	

## PIECE TO BE WELDED

Description	
Code	Thickness
Material	Coating

## WELDING PARAMETER ADJUSTMENT

Foreseen working with: <input type="checkbox"/> FOOT-CONTROL <input type="checkbox"/> TWO-HANDS CONTROL DEVICE	
Cycle foreseen working : <input type="checkbox"/> SINGLE <input type="checkbox"/> REPEAT	
Is during production foreseen the use of double stroke: <input type="checkbox"/> YES <input type="checkbox"/> NO	
Welding pressure adjustment bar	Reached welding current kA
Working stroke adjustment mm	Double stroke adjustment mm

## WELDING CONTROL UNIT TE600 PARAMETERS

SQUEEZE TIME 1	
SQUEEZE TIME	
FORGE DELAY	
WELDING PRESSURE	
PRE-WELD TIME	
PRE-CURRENT	
COLD 1 TIME	
SLOPE UP TIME	
WELD1 TIME	
CURRENT 1	
COLD 2 TIME	
IMPULSE NUMBER	
WELD 2 TIME	
CURRENT 2	
COLD 3 TIME	
WELD 3 TIME	
CURRENT 3	
SLOPE DOWN TIME	
COLD 4 TIME	
POST-WELD TIME	
POST-CURRENT	
HOLD TIME	
OFF TIME	
LIMIT CURRENT MIN	
LIMIT CURRENT MAX	

